



FORMOSA No-clean Lead-Free ,Halide-Free Solder Paste Model: PF606-P30

Rev. 2012/10/16 Ver. 03-00

| - Specification- | | | | | | | | |
|-------------------|---|---------------------|--|--|--|--|--|--|
| Item | Specification | Standard | | | | | | |
| Appearance | Gray paste w/o visible foreign and clusters | | | | | | | |
| Alloy composition | Sn/Ag3.0/Cu0.5/X | JIS-Z-3282 | | | | | | |
| Melting Point | 217~219 ℃ | | | | | | | |
| Particle Size | (Type 3) $+45\mu m < 1\%$, $-20\mu m < 10\%$ (Type 4) $+38\mu m < 1\%$, $-20\mu m < 10\%$ (Type 5) $+25\mu m < 1\%$, $-15\mu m < 10\%$ (Type 6) $+15\mu m < 1\%$, $-5\mu m < 10\%$ | IPC-TM-650, 2.2.14 | | | | | | |
| Powder Shape | Spherical | | | | | | | |
| Flux Content | 11.5 ± 1.0wt% | JIS-Z-3197, 8.1.2 | | | | | | |
| Viscosity | 200 ± 30 Pa ⋅ s (25±1 °C, 10rpm, Malcom) | JIS-Z-3284, Annex 6 | | | | | | |
| Flux Type | ROL0 | J-STD-004A | | | | | | |

– Test Content–

| Test Item | Test Result | Test Method | | | | |
|-----------------------------|-----------------|----------------------------|--|--|--|--|
| Copper Plate Corrosion Test | Pass | JIS-Z-3197, 8.4.1 | | | | |
| Spreading Test | > 70% | JIS-Z-3197, 8.3.1.1 | | | | |
| Ion Chromatography Test | 0.0 wt% | IPC-TM-650 Method 2.3.28.1 | | | | |
| Copper Mirror Test | Pass | IPC-TM-650, 2.3.32 | | | | |
| Viscosity Test(25°C,10rpm) | 200 ± 30 Pa · s | JIS-Z-3284. Annex 6 | | | | |
| Tackiness Test (gf) | > 130 (8hr) | JIS-Z-3284. Annex 9 | | | | |
| Slump Test | Pass | JIS-Z-3284. Annex 7, 8 | | | | |
| Solder Ball Test | Pass | JIS-Z-3284. Annex 11 | | | | |

| | elia | bilit | V 10 | \sim |
|-----------|------|-------|------|---------------------|
| $-\infty$ | ena | ısını | VIE | $oldsymbol{s}\iota$ |

| S.I.R. Test | A | > 1×10 ⁹ Ω, Pass | IPC-TM-650, 2.6.3.3 |
|------------------------|----------|-----------------------------|----------------------|
| Electro Migration Test | • | Pass | IPC-TM-650, 2.6.14.1 |

▲ Test Conditions : 85 \mathcal{C} , 85% RH for 168 hrs ◆ Test Conditions : 65 \mathcal{C} , 88.5% RH for 596 hrs






Alloy Composition

| (Sn) | (Ag) | (Cu) | (Ni) | (Ge) | (Zn) | (AI) | (Sb) | (Fe) | (As) | (Bi) | (Cd) | (Au) | (In) | (Pb) |
|------|------|------|------|------|-------|-------|------|------|------|------|-------|------|------|------|
| REM. | 2.8~ | 0.3~ | 0~ | 0~ | 0.001 | 0.001 | 0.05 | 0.02 | 0.03 | 0.10 | 0.002 | 0.05 | 0.10 | 0.05 |
| | 3.2 | 0.7 | 0.01 | 0.01 | MAX | MAX | MAX | MAX | MAX | MAX | MAX | MAX | MAX | MAX |

Patent No.: Japanese Patent No. 3296289 · U.S Patent No. 6179935B1 · Germany Patent No. 19816671C2.

(wt%)

– Temperature Profile-



ramp up rate(30~150 $^{\circ}$ C): 1.0~2.0 $^{\circ}$ C/sec pre-heating time(155~185 $^{\circ}$ C): 30~120 sec time period above 220 $^{\circ}$ C: 30~100 sec ramp up rate during reflow: 1.0~2.0 $^{\circ}$ C/sec peak temperature: 230~250 $^{\circ}$ C ramp down rate during cooling: 1.0~6.0 $^{\circ}$ C/sec





Handling and Storage Instructions—

1. Storage

- (1) Refrigerate pastes at 0~10 °C helps prolong shelf life; normal shelf life is 6 months from production date (sealed jars).
- (2) Keep away from direct sunlight.

2. Operation Manual (Sealed)

- (1) Allow pastes to reach ambient printing temperature prior to use for 3-4 hrs. Do not heat to raise temperature abruptly.
- (2) Well mix paste with plastic spatula for 1-3 mins before use. Mixing time depends on tool type.

3. Operation Manual (Opened)

- (1) At first, add 2/3 jar of solder paste onto the stencil. Do not add more than 1 jar.
- (2) Add a little amount of paste at a time on the stencil according to printing speed.
- (3) It is recommended to finish fresh paste within 24 hrs. To maintain paste quality, make sure not to store used paste and fresh paste in the same jar.
- (4) After printing, it is suggested to place components to be mounted on the circuit board and reflow within 4-6 hrs.
- (5) If printing process was interrupted for more than 1 hr, be sure to remove paste remnant from stencil and seal them in the jar.
- (6) It is recommended to keep printing environment at 22~28 °C and RH of 30~60%.
- (7) To clean up printed circuit boards, it is suggested to use ethanol or isopropanol.

Contact Information

SHENMAO TECHNOLOGY INC.

Add: No.12-1 Gongye 2nd Rd., Guanyin industrial area, Taoyuan County 328, Taiwan

Tel: (886)3-416-0177 Fax: (886)3-416-0133 Mail: sales@shenmao.com

BRANCHES:

Please refer to our website.

Website: http://www.shenmao.com